

Pizza paddle flat

Article number: SR312

For use with Merrychef eikon® model(s):

e2 e2s e3 e4 e4s e5

Key benefits:

- Enables the taking of food in and out of your high speed oven
- Easy to clean
- Lightweight aluminium paddle



Specifications:

- Dimensions: 300 mm x 215 mm (11.8" x 8.5")

Recommended application:

To be used for taking all food items in and out of the high speed oven

Cleaning:

Wipe clean with a soft cloth or sponge in warm soapy water. To avoid damage always follow the recommended cleaning procedure. Do not use hard abrasives or wire wools on accessories.

Dimensions:

